


SPARE PARTS



<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Quantity</u>
1	16-064	Complete Foot Pedal	1
2	16-065	3 Way Foot Pedal Valve	1
3	16-055	Self Leveling Double Clamp	1
4	16-013	Magnet	1
5	16-043	Pusher (4mm, 7mm)	1
6	16-044	Pusher (10mm, 12mm, 15mm)	1
7	04-344	4mm Compensator	1
8	16-041	7mm Compensator	1
9	16-042	10mm Compensator	1
10	04-347	12mm Compensator	1
11	16-039	Flat Angular Pad	1
12	16-040	Flat Angular Pad Screw	1
13	16-037	Round Angular Pad	1
14	16-036	Round Angular Pad Screw	1
15	16-038	Round Angular Pad Bushing	1
16	16-074	Hex Wrench Set (5)	1
17	16-061	Locking Knob	2
18	16-063	Stop Locking Knob	2
19	16-075	Push Button and Valve	1
20	16-006	Guard Knob	1
21	16-005	Guard Valve	1
22	16-066	Loader Toggle Switch and Valve	1
23	16-067	Automatic/Manual Switch and Valve	1
24	16-054	Cylinder Gasket Set	1
25	16-051	Nail Loader	1
26*	16-062	1-1/2" (40mm) Round Pad	1

* Not shown